


FIG. 1

FIG. 2









FIG. 5





TO 110

FROM 128

FIG. 6B

FROM 112

116

DIALOGUE BOX DEACTIVATE EQUIPMENT

⇒ DISPLAY UPDATED CHARGES  
⇒ ASK TO CONFIRM DEACTIVATION

136

USER INPUT:

⇒ CONFIRM DEACTIVATION  
⇒ CANCEL AND CONTINUE USAGE

138

DIALOGUE BOX: PRINTING OF RECEIPT OPTIONS

◆ REQUEST PRINTING OF RECEIPT W/CC ACCOUNT  
◆ REQUEST PRINTING OF RECEIPT WO/CC ACCOUNT  
◆ REQUEST NO PRINTING OF RECEIPT

140

USER INPUT:

SELECT PRINTING OF RECEIPT

142

⇒ PRINT RECEIPT PER USER INPUT.  
⇒ POWER OFF TO EQUIPMENT VIA SWITCHBOX.

130

DIALOGUE BOX: MAX DURATION EXCEEDED

⇒ DISPLAY WARNING OF MAXIMUM DURATION EXCEEDED  
⇒ DISPLAY OPTION TO CONTINUE USAGE.

USER INPUT:


• CONTINUE USAGE  
• DEACTIVATE EQUIPMENT  
• NO RESPONSE

132

⇒ IF NO RESPONSE, POWER OFF TO EQUIPMENT  
⇒ PRINT RECEIPT WO/CC ACCOUNT INFORMATION.

134

FIG. 7A








FIG. 8






FIG. 9










Figure 11

002077 19920260

FIGURE 12





**FIGURE 13**  
**500**